

1. Manufacturer combination coded:

0-0-0(as figure 1)

2. Reset your desired new codes :

a) Make sure it's unlocked

b) Use a small, sharp object such as screw driver or pencil to point into the reset button hole (as figure 2) and hold it until adjust the number wheels to the new sequence codes then release the sharp object. The new code is setting up .

c) To change a new code, just repeat the above two steps a and b .

d) Always write down your code number and keep it in a safe place .

3. To unlock :

- Adjust the number wheels to the codes sequence your preset.

- To rotate the Revolver from lock position to unlock position .

(as figure 3)

4. To lock :

- To rotate the Revolver from unlock position to lock position .

(as figure 4)

- Adjust the wheels randomly to lock it .




figure 1




figure 2





figure 3



Revolver

figure 4