



Installation Manual




Components list



Pre-installation

TOOLS REQUIRED




HARDWARE INCLUDED

A (x1) ST4.2x50 (x4) Ø8 (x4)	B Left(x1) Right(x1)	C (x1) ST3.5x13(22)	D (x1) (x1) ST2.9x9.5(x2)
E (x2) ST4.2x25 (x4)	F (x1)	G (x1) Ø8 (x2) ST4.8x38 (x2)	(x1)



Door preparation.a

DW	Door Width
PD	Passage Width
DH	Door Height
PH	Passage Height
MH	Hanger Positioning





Door preparation.b

DW	Door Width
PD	Passage Width
DH	Door Height
PH	Passage Height
MH	Hanger Positioning




Door preparation.c

DW	Door Width
PD	Passage Width
DH	Door Height
PH	Passage Height
MH	Hanger Positioning




Components position




Open top and bottom slots



Top Track




Bottom Slot



Tool







Section drawing









Installation


1 Fasten top track onto the door slot.




2 loosen the soft close screws and put both soft closes on both ends of top track.



3 Ensure soft close is even with either end of track and tighten soft close screws.



4 Install end caps and secure with screws.



5 Remove the wheel.


E



(x2)



ST4.2x25 (x4)



6 Fasten the bottom wheel body first.



E




(x2)



ST4.2x25 (x4)





7 Put the wheel part back in the body.




8 Cut bottom track to length (door width-130mm) and put the bottom track inside the bottom slot.


F




9a Remove anti-jump block of hanger first and mount hanger onto the wall.




10a Mount floor guide.




9b Remove anti-jump block of hanger first and mount hanger onto the wall.




10b Mount floor guide.




9c Remove anti-jump block of hanger first and mount hanger onto the wall.



10c Mount floor guide.



14 Move the door both left and right to ensure actuator is in between the fins of soft close.



15 Adjust the door to ensure it is parallel with wall.

